Part List, Mechanical

Applicable for R320s and R320sc

Contents

1 Exploded View **2**
1.1 R320s and R320sc 2
2 Part List **3**
2.1 R320s and R320sc 3
3 Revision History **4**

1 Exploded View

1.1 R320s and R320sc



2 Part List

2.1 R320s and R320sc

Pos.	Description	Part Number	Comments
1	Volume button	SXA 104 2620	
2	Warranty seal	SVF 930 113	
3	Front cover Latin R-R	SXK 107 6941	
3	Front cover Latin B-G	SXK 107 6941/2	
3	Front cover Latin Lilac	SXK 107 6941/3	
3	Front cover China R-R	SXK 107 6941/11	
3	Front cover China B-G	SXK 107 6941/12	
3	Front cover China Lilac	SXK 107 6941/13	
4	Buzzer gasket	SXA 104 2629	
5	Speaker gasket	SXA 104 4428	
6	Display assembly	SXK 107 6940/Z	
7	Keyboard, Latin	SXA 104 0012	
7	Keyboard, Arabic	SXA 104 0012/2	
7	Keyboard, Hebrew	SXA 104 0012/3	
7	Keyboard, Cyrillic	SXA 104 0012/4	
7	Keyboard, China	SXA 104 0012/11	
8	Loudspeaker	RLE 906 23/1	
9	Speaker support	SXA 104 4498	
10	Elastomeric connector	SXA 104 7557	
11	Antenna NCS S 7020-R	KRE 101 1079/5	
11	Antenna NCS S 7020-B10G	KRE 101 1079/6	
11	Antenna NCS S 8010-R50B	KRE 101 1079/7	
12	Mic rubber	SXA 104 4422	
13	Microphone	RLC 509 405	
14	Plug/frame	SXA 104 8324	
15	Vibration motor	BKE 902 019/2	
16	Screw	SXA 104 6780	
17	Grommet/mic	SXA 104 6273	
18	Plug rubber (clip)	SXA 104 6278	
19	Pressure pad (battery)	SXA 104 7538	
	Chris Clip	SXK 109 72/01	

3 Revision History

Rev.	Date	Changes / Comments
A	2000-01-17	
B	2000-03-15	Component removed: RF-Shielding/Gasket SXA 104 8421 Document title and layout changed
C	2000-05-24	Pos. numbers corrected in Part List.
D	2000-06-07	Chris Clip, SXK 109 72/01 added.